



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

110382
Dining Side Chair

ITEM: 110382



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!






1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.









ASSEMBLY TIME

15 MINUTES

PART IDENTIFICATION

| | | | |
|---|------------|--|------|
| A | BACK FRAME |  | 1PC |
| B | SEAT |  | 1PC |
| C | FRONT LEG |  | 2PCS |

HARDWARE IDENTIFICATION

| | | | |
|---|--|--|-------|
| 1 | LONG BOLT (Ø1/4" x 3-1/4" - RBW) |  | 4PCS |
| 2 | MEDIUM BOLT (Ø1/4" x 2" - RBW) |  | 4PCS |
| 3 | SHORT BOLT (Ø1/4" x 1-1/2" - RBW) |  | 2PCS |
| 4 | LOCK WASHER (Ø1/4" - RBW) |  | 10PCS |
| 5 | FLAT WASHER (Ø1/4" - RBW) |  | 10PCS |
| 6 | ALLEN WRENCH (4MM - RBW) |  | 1PC |


NOTE:

Quantities shown are for one chair.


ITEM: **110382**

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3 **COMPLETE**



ITEM: 110382



Note: Dimension tolerance $\pm 5\%$