


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

316031T Twin Headboard

REVISION 0 : 11/28/2021

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM:316031T

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION


Α	HEADBOARD PANEL		1PC
В	RIGHT HEADBOARD LEG		1PC
С	LEFT HEADBOARD LEG		1PC
HARDWARE IDENTIFICATION			
1	ALLEN WRENCH (M4-BLK)		1PC
2	SHORT BOLT (M6 x 40mm-RBW)		6PCS
3	FLAT WASHER (M6-RBW)		18PCS
4	LOCK WASHER (M6 - RBW)	P	18PCS
5	HEX NUT		6PCS
6	WRENCH		1PC
7	LONG BOLT (M6 x 45mm - BLK)		6PCS

ITEM:316031T


COASTER

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2



STEP 3 COMPLETE


FRONT VIEW





ITEM: 316031T





Note: Dimension tolerance ±5%