
Item Number: 41310641

WARNING (To reduce the risk of fire, electric shock, or personal injury):


- 1. We suggest installation by a licensed electrician.
- 2. Please read the instruction carefully and save it as you may need it at a later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done.
 - **»** Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "**OFF**" position.
 - » Place the wall switch in the "OFF" position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all sides. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before installation.
- 6. Make sure the voltage you are using is 120V. The maximum wattage is Type B, Max 40W per bulb.
- 7. Keep the lamp away from acidic and alkaline substances in case of damaging the surface of the lamp.
- 8. When replacing bulbs, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- 9. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

IMAGE FOR FINISHED PRODUCT:



TOOLS REQUIRED (NOT INCLUDED):

Before starting assembly and installation please prepare the needed tools as below picture




PARTS TYPE & QTY INCLUDING:

- (C) Mounting plate (1)
- (D) Green ground screw (1)
- (E) Canopy (1)
- (F) Swivel joint (1)
- (G) Knob nut (2)
- (H) Tube
- (I) Pipe (1)
- (J) Arm (3)
- (K) Socket (3)
- (L) Lampshade (3)
- (M) Socket ring (3)
- (O) Cover (3)



- (A) Plastic wire connector (3)
- (B) Mounting screw (2)
- (N) Allen wrench (1)



C

D

Н


ASSEMBLY & INSTALLATION INSTRUCTIONS:

- 1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration.
- 2. Turn off power


Before you start the installation, NEVER attempt any work without shutting off the electricity until the work is done.

В


- **>>** Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "**OFF**" position.
- » Place the wall switch in the "OFF" position.
- 3 » Unscrew knob nuts (G) from canopy (E) and then gently remove mounting plate (C).



- 4 » 1) Screw covers (O) to arms (J) as shown in the illustration.
 - 2) According to your desired hanging height to choose and use tubes (H).
 - 3) Then pass the fixture wires through the chosen tubes (H), swivel joint (F) and canopy (E).
 - 4) Screw the chosen tubes (H) into swivel joint (F) and the top of pipe (I) and then hand tighten till snug.
 - 5) Adjust arms (J) to proper position.



5 » Attach mounting plate (C) to the outlet box with mounting screws (B).




6 » Make wire connections

Connect wires as below wires connection shown. PLEASE NOTE THAT GROUND WIRE IS BARE COPPER WIRE, NEVER CONNECT OTHER WIRES TO GROUND WIRES.

smooth (see illus.)

Connect ground wires according to the below chart



Connect wires according to the below chart

Connect wires according to the below chart	
Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
Black	White
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer
Insulated wire(other than green) with copper conductor	Insulated wire(other than green) with silver conductor
* Note: When parallel wires (SPT I& SPT II) are used. The neutral wire is square shaped or ridged and the other will be round in shape or	


Neutral Wire

- Twist wires together with plastic wire connectors (A) until tightly joined.
- Wrap each connector with approved electrical tape.
- Be sure that no wire strands are exposed and then carefully tuck all wires into the outlet box.
- 7 » Raise canopy (E) to the ceiling and secure canopy (E) in place by tightening knob nuts (G) onto the pre-assembled screws in mounting plate (C).


Note: canopy (E) should be snug against the ceiling and knob nuts (G).

If not, adjust the threaded length on mounting plate (C):

- Unscrew the pre-assembled hex nuts.
- Screw the pre-assembled screws in or out of mounting plate (C).
- When the secure length is achieved, tighten the hex nuts and back to step 7.



- 8 » 1) Remove socket rings (M) from sockets (K).
 - 2) Place lampshades (L) to sockets (K) and then using socket rings (M) to secure them..
 - 3) Install bulbs (Not included) (Please do not exceed the maximum wattage recommended on the socket.)
 - If you feel arms (J) is too loose, the Allen wrench (N) could be used to lock them.
 - The angle of arms (J) and sockets (K) could be adjusted as shown in the illustration.



9. Check everything is already installed properly, then you could turn on the light. Enjoy!

ORDERING PARTS

Keep this sheet for future reference in case you need to order replacement parts. All parts for this fixture can be ordered from the place of purchase. Be sure to use exact wording from illustration when ordering parts.

CLEANING

To clean, wipe the fixture with a soft cloth. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.