Thank You For Shopping With COZAYH HOME

We value your feedback and want to hear from you. To let us know how we can improve your shopping experience, or to ask a specific question about your order, please find our contact information below.

Customer Service Line: 1.312.600.5553 (M-F 9am-5pm Central Time)

Customer Service Email: Support@cozayh.com

Website: www.cozayhhome.com



Assembly Instructions

Laying out all the parts and hardware and identifying each part as shown may help you assemble the table.

ITEM	PART	QTY	ITEM	PART	QTY	ITEM	PART	QTY	ITEM	PART	QTY	ITEM	PART	QTY
ITEM	PARI	QIT	I I ⊏IVI	PART	QIT	I I ⊏IVI	PARI	QII	I I E IVI	PARI	QIT	I I EIVI	PARI	QII
Α		1	В	Carried to	1	С		1	D		1	E		1
	Table Top			Right Panel			Left Panel			Back Panel			Bottom Panel	
F		1	G		1									
	Door Panel			Shelf Panel										

F	11	8*30mm	8	H2	Flat Washer	8	НЗ	Hinge Pin	2	H4	Handle	1	H5	Levelling Foot	4
\vdash		0 00111111		-	i lat vvasilei			rillige r ill			Tidifale			Levelling 1 oot	
ŀ	1 6		1	H7		1									
		4*22mm			Allen Wrench										

NOTE: Using wrong sized screws will cause permanent damage.

NOTE: Do NOT fully tighten the screws until the frame panels are properly attached.




WARNING


- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Choking Hazard Adult assembly required. It may contain small parts and sharp points.
- Do NOT use power tools.
- This product can hold a maximum load of 25 Lbs. Do NOT overload.



COZAYH HOME




STEP 4




Screw in levelling feet and adjust as needed.

STEP 5



Flip the assembly. Align the hinge leafs together on door panel H and right panel B. Insert hinge pin H3 through the hollow knuckle.

STEP 6



Properly sit atop shelf panel G.

