

Fine Furniture for every stage of life

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

#### **PARTS IDENTIFICATION**


A	COFFEE TABLE TOP	1PC
В	COFFEE TABLE LONG APRON	2PCS
С	COFFEE TABLE LEG	4PCS
D	END TABLE TOP	2PCS
E	END TABLE LEG	8PCS
F	END/COFFEE TABLE SHORT APRON	10PCS
G	CORNER BLOCK	12PCS

#### HARDWARE IDENTIFICATION


1	ALLEN WRENCH (M4 x 110mm - BLK)	1PC
2	BOLT (M6 x 70mm - RBW)	62PCS
3	LOCK WASHER (5/16" - RBW)	24PCS
4	FLAT WASHER (5/16" - RBW)	24PCS

# ASSEMBLY INSTRUCTIONS COFFEE TABLE


### STEP 1




### STEP 2




### STEP 3




# STEP 4 COMPLETE




## END TABLE STEP 5




### STEP 6




### STEP 7




# STEP 8 COMPLETE









Note: Dimension tolerence ± 5%