# ASSEMBLY INSTRUCTIONS



Fine Furniture for every stage of life

### **ASSEMBLY INSTRUCTIONS**

### **ASSEMBLY TIPS:**

1. Remove hardware from box and sort by size.

2. Please check to see that all hardware and parts are present prior to start of assembly.

3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.


#### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



30 MINUTES

### PARTS IDENTIFICATION




### **HARDWARE IDENTIFICATION**

_	•						
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 15g		1 PC	5	SCREW Ø4.5x42mm SR	attitutu 18	6 PCS
2	WOODEN DOWEL Ø8x30mm		14 PCS	6	SCREW Ø5x19mm BLK		16 PCS
3	CAM BOLT Ø7x35.5mm SR		4 PCS	7	PLASTIC FEET		4 PCS
4	CAM LOCK Ø15x12mm SR		4 PCS	8	STICKER Ø20mm		1 PC


#### NOTE:

7


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.




## STEP 2











## STEP 5






# STEP 6



## COMPLETE







Note : Dimension tolerance ±5%