

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

905613 ACCENT CHAIR

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM: 905613 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

PARTS IDENTIFICATION


A		SEAT	1PC
В		BACK	1PC
С		FRONT LEG FRAME	1PC
D		BACK LEG FRAME	1PC
E	· · · · · · · · · · · · · · · · · · ·	CROSSBAR	2PCS
Z HARDWARE IDENTIFICATION			
1		BOLT (M6x40MM)	9PCS
2		ALLEN WRENCH (M5)	1PC


PAGE 2 OF 3

COASTERFURNITURE.COM

ITEM: 905613


ASSEMBLY INSTRUCTIONS









STEP 4



STEP 5




STEP 6



PAGE 3 OF 3

ITEM: 905613 ASSEMBLY INSTRUCTIONS





Noted: Dimension tolerance ±5%