



ASSEMBLY INSTRUCTION

SKU CODE: WF302186















Detail View - QUEEN BED














Identifying the Hardware - Indentify the hardware using the illustrations below.

Part Lists: **WF302186**

<div data-bbox="124 143 156 174">1</div>  <div data-bbox="566 331 774 360">Headboard-1pc</div>	<div data-bbox="834 143 866 174">2</div>  <div data-bbox="1177 331 1490 360">Headboard left leg -1pc</div>
<div data-bbox="124 376 156 407">3</div>  <div data-bbox="464 560 783 589">Headboard right leg-1pc</div>	<div data-bbox="834 376 866 407">4</div>  <div data-bbox="1273 560 1497 589">Side rail 1 - 2pcs</div>
<div data-bbox="124 600 156 631">5</div>  <div data-bbox="566 784 790 813">Side rail 2 - 2pcs</div>	<div data-bbox="834 600 866 631">6</div>  <div data-bbox="1137 784 1490 813">Side rail support leg - 2pcs</div>
<div data-bbox="124 824 156 855">7</div>  <div data-bbox="528 1008 790 1037">Footboard leg -2pcs</div>	<div data-bbox="834 824 866 855">8</div>  <div data-bbox="1273 1008 1490 1037">Footboard - 1pc</div>
<div data-bbox="124 1048 156 1079">9</div>  <div data-bbox="566 1232 790 1261">Bed slat 1 - 4pcs</div>	<div data-bbox="834 1048 866 1079">10</div>  <div data-bbox="1273 1232 1490 1261">Bed slat 2 -6pcs</div>
<div data-bbox="124 1272 156 1303">11</div>  <div data-bbox="459 1456 790 1485">Center support bar -2pcs</div>	<div data-bbox="834 1272 866 1303">12</div>  <div data-bbox="1153 1456 1490 1485">Center support leg - 4pcs</div>

HARDWARE LISTS: WF302186

A  4mm Allen key (1pc)	B  Ø5/16" x 20mm Hex-head bolt (8pcs)
C  Ø5/16" x 40mm Hex-head bolt (4pcs)	D  Ø5/16" Spring washer (12pcs)
E  Ø5/16" Flat washer(12pcs)	F  Ø1/4" x 45mm Hex-head bolt (4pcs)
G  Ø1/4" x 30mm Hex-head bolt (8pcs)	H  Ø1/4" Spring washer (12pcs)
I  Ø1/4" Flat washer(12pcs)	J  Ø4 x 30mm Wood screw (20pcs)
 ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)	




Read this instruction carefully. See hardware and furniture part list for guidance.
Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched.
Follow the figure to start assembling.


CAUTIONS :

1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.
2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.
3. Keep all hardware parts out of reach of children.


NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

STEP 1

E		D		C	
4PCS		4PCS		4PCS	




STEP 2







STEP 3

I	H	G
8PCS	8PCS	8PCS







STEP 4

E		D		B	
8PCS		8PCS		8PCS	




STEP 5

I		H		F	
4PCS		4PCS		4PCS	



STEP 6

J

20PCS

