








Thank You For Shopping With COZAYH HOME

We value your feedback and want to hear from you. To let us know how we can improve your shopping experience, or to ask a specific question about your order, please find our contact information below.


Customer Service Line: 1.312.600.5553 (M-F 9am-5pm Central Time)

Customer Service Email: Support@cozayh.com

Website: www.cozayhhome.com


		SKU: PH03078 <h2 style="text-align: center;">Assembly Instructions</h2> <p style="text-align: center;">Laying out all parts and hardware and identifying each part as shown may help you assemble the table.</p>									
ITEM	PART	DESC.	QTY	ITEM	PART	DESC.	QTY	ITEM	PART	DESC.	QTY
A		Table top	1	C		Female Leg	1	E		Allen wrench	1
B		Male Leg	1	D		Bolts (Ø6×50 mm)	4	F		Flat washers	4

STEP 1




Flip table top A upside down. Attach male leg B to the bottom of table top A.

STEP 2



Interlock the female leg C in the wood slot and attach to bottom of table top A.

STEP 3



Please make sure all bolts are fully tightened before using this table.



WARNING

- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Choking Hazard – Adult assembly required. It may contain small parts and sharp points.
- Do NOT use power tools.
- This product can hold a maximum load of 25 Lbs. Do NOT overload.



COZAYH HOME