













CROSLEY

FURNITURE







Record Storage Stand CF1123



PART LIST

<div data-bbox="177 217 220 264">A</div> 	<div data-bbox="426 217 469 264">B</div> 	<div data-bbox="675 217 718 264">C</div> 	<div data-bbox="924 217 967 264">D</div> 	<div data-bbox="1173 217 1216 264">E</div> 
<div data-bbox="236 479 363 591">Front Top Panel 1 PC</div>	<div data-bbox="478 479 632 591">Front Lower Panel 1 PC</div>	<div data-bbox="730 479 858 591">Left Panel 1 PC</div>	<div data-bbox="973 479 1114 591">Right Panel 1 PC</div>	<div data-bbox="1206 479 1382 591">Bottom Panel 1 PC</div>
<div data-bbox="177 591 220 638">F</div> 	<div data-bbox="426 591 469 638">G</div> 	<div data-bbox="675 591 718 638">H</div> 	<div data-bbox="924 591 967 638">I</div> 	<div data-bbox="1173 591 1216 638">J</div> 
<div data-bbox="225 853 373 965">Fixed Shelf 3 PCS</div>	<div data-bbox="472 853 628 965">Upper Back Panel 1 PC</div>	<div data-bbox="718 853 874 965">Lower Back Panel 1 PC</div>	<div data-bbox="954 853 1139 965">Partition Panel 2 PCS</div>	<div data-bbox="1197 853 1394 965">Lower Partition Panel 1 PC</div>
<div data-bbox="177 965 220 1012">K</div>  <div data-bbox="268 1234 322 1267">Leg</div> <div data-bbox="252 1312 338 1346">4 PCS</div>				

HARDWARE LIST

#1		#2		#3		#4		#5	
	Ø1/4"*1-1/2"		Ø1/4"		Ø1/4"		Ø8*30mm		4mm
	Bolt		Flat Washer		Spring Washer		Wood Dowel		Allen Wrench
	8 PCS (Extra 1)		8 PCS (Extra 1)		8 PCS (Extra 1)		36 PCS (Extra 4)		1 PC
#6									
	Safety Strap Kit								
	1 SET								

ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver


Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Please do not use tools to assemble this unit unless specifically indicated.




Reference the images above any time the instructions state "lock the hardware".
Be sure to check all hardware is locked when complete.


Step 1. Attach legs (part K) to bottom panel (part E) using spring washers (part #3), flat washers (part #2), bolts (part #1) and allen wrench (part #5).




Step 2. Attach upper back panel (part G) to right panel (part D) using wood dowel (part #4) and lock the hardware.



Step 3. Attach fixed shelf (part F) to upper back panel (part G) using wood dowels (part #4) and lock the hardware.




Step 4. Attach partition panel (part I) to assembled unit (parts D & F) using wood dowels (part #4) and lock the hardware.




#4  x 4

Step 5. Attach fixed shelf (part F) to partition panel (part I) using wood dowels (part #4) and lock the hardware.




#4  x 2


Step 6. Attach partition panel (part I) to assembled unit (parts D & F) using wood dowels (part #4) and lock the hardware.




Step 7. Attach fixed shelf (part F) to partition panel (part I) using wood dowels (part #4) and lock the hardware.




Step 8. Attach front top panel (part A) to fixed shelf (part F) and right panel (part D) using wood dowels (part #4) and lock the hardware.




Step 9. Attach lower partition panel (part J) to lower back panel (part H) using wood dowel (part #4) and lock the hardware.




Step 10. Attach assembled unit (parts H & J) to bottom panel (part E) and lock the hardware.




Step 11. Attach front lower panel (part B) to assembled unit (parts E & J) using wood dowels (part #4) and lock the hardware.




#4  x 3

Step 12. Attach assembled unit (parts B, E & H) to right panel (part D) using wood dowels (part #4) and lock the hardware.




Step 13. Attach left panel (part C) to assembled unit (parts A, B, E, G, H & I) using wood dowels (part #4) and lock the hardware.









Step 14. Carefully turn unit upright.

Note: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.

Important: Safety strap kit (part #6) must be installed to prevent tipping, damage and /or injury.




#6	A	B	C	D	E
			 D8*3/4"	 D8*1-1/2"	
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Washer 2 PCS	Short Screw 1 PC	Long Screw 1 PC	Safety Wall Strap 1 PC

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) through washer (B) and safety wall strap (E) and attach to upper back panel (part G) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in upper back panel (part G) where the safety wall strap (E) is attached. Tap wall anchor (A) into the hole.
3. Insert long screw (D) through washer (B) and safety wall strap (E) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING	
	<p>Children have died from furniture tipover. To reduce the risk of furniture tipover:</p> <ul style="list-style-type: none"> • ALWAYS install tipover restraint provided. • NEVER put a TV on this product. • NEVER allow children to stand, climb or hang on drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heaviest items in the lowest drawers. <p><i>This is a permanent label. Do not remove!</i></p>
	