

CROSLEY FURNITURE


Large Record Storage Media Console CF1127



PART LIST



HARDWARE LIST



ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.


Please do not use tools to assemble this unit unless specifically indicated.




Reference the images above any time the instructions state "lock the hardware" or "insert hardware and pull down to lock".

Be sure to check all hardware is locked when complete.


Step 1. Insert metal leg frames (part H) into metal bars (part G).




Step 2. Secure metal bars (part G) and metal leg frames (part H) using bolts (part #2) and allen wrench (part #5).




Step 3. Attach assembled unit (parts G & H) to bottom panel (part D) using bolts (part #2) and allen wrench (part #5).




Step 4. Attach panels (parts B, C & E) to bottom panel (part D) by inserting hardware and pull down to lock.




Step 5. Carefully turn unit upright. Insert back panels (part F) into grooves of assembled unit (parts B, C, D & E).



Step 6. Attach top panel (part A) to assembled unit (parts B, C & E) using wood dowels (part #3) and lock the hardware.



Step 7. Secure back brackets (part #4) at the corner of back panels (part F) using screws (part #1) and phillips head screwdriver.



Note: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.

