


# ASSEMBLY INSTRUCTIONS

---



## TOOLS REQUIRED




Allen Wrench

(Included)



Phillips  
Screwdriver

(Not Included)



2 - People  
Recommended

## ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



## **CHECK BEFORE STARTING**

☐

### **Are you missing anything?**

Double-check all parts, hardware and accessories listed are all accounted for.

☐

### **Check out our Quick Tips!**

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

### **Should we send any replacements?**

Are there any irregularities or flaws in the parts? We can send replacements!


☐

### **Prep Time!**

Please review the assembly instructions and all diagrams prior to assembling.



# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



## Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




## Suitable Location

Assembling near the area of the intended location is highly recommended.





## Sufficient Space

Make sure you have enough space to move around during the assembly.



## Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



## Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


# ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY  
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly  
and insert screws or bolts into  
their respective holes.




Turn clockwise to tighten and  
only tighten when step is  
completed or when instructed  
to do so.



Use the appropriate hand tools  
or power tools for assembly.  
Select steps, such as tightening  
screws and/or bolts, may require  
hand tools to avoid causing  
damage during assembly.



Save the instructions and store  
any supplied tools for later  
maintenance.




After two weeks, check and  
tighten any loose hardware and  
repeat again every six months  
thereafter.

**IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.**

# CHAIR



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




## PARTS

#1 1pc x 2




Chair Back

#2 1pc x 2



Cushion Seat

#3 2pcs x 2



Front Leg

## HARDWARE

#A 2pcs x 2



Bolt  
Ø1/4" x 1-1/2"

#B 4pcs x 2



Bolt  
Ø1/4" x 2-3/8"

#C 4pcs x 2



Bolt  
Ø1/4" x 3"

#D 10pcs x 2



Lock Washer  
Ø1/4"

#E 10pcs x 2



Flat Washer  
Ø1/4"x19mm

#F 1pc x 2




Allen Wrench  
4mm

#G 1pc x 2



Wooden Dowel  
(Ø10 x 30mm)

# Exploded View



# ASSEMBLY INSTRUCTIONS

## 1

Part **#1** x1pc

Part **#2** x1pc


Hardware **#A** x2pcs

Hardware **#D** x2pcs

Hardware **#E** x2pcs

Hardware **#G** x1pc

Use Dowel (**#G**) to align the Cushion Seat (**#2**) to the Chair back (**#1**). Secure by using Bolt (**#A**) with Lock Washer (**#D**) and Flat Washer (**#E**).




## 2

Hardware **#C** x4pcs

Hardware **#D** x4pcs

Hardware **#E** x4pcs

Secure corners of the Cushion Seat (**#2**) to the Chair back (**#1**) legs by using Bolt (**#C**) with Lock washer (**#D**) and Flat washer (**#E**).



# ASSEMBLY INSTRUCTIONS

## 3


Part #3 x2pcs

Hardware #B x4pcs


Hardware #D x4pcs

Hardware #E x4pcs

Align and secure the Front leg (#3) to the Cushion Seat (#2) and secure by using Bolt (#B) with Lock washer (#D) and Flat washer (#E).



## 4



## ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



### Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



### Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.