














Product Name	Accent Chair Living Room Upholstered Gray Armchair
SKU #	WHIF1797

A		1PCS
B		1PCS
C		1SET
D		1PCS
E		2PCS
F	 M6 x 50mm	7PCS
G	 M8 x 50mm	3PCS
H	 M6 x 70mm	2PCS
I	 M8 x 22mm	3PCS
J	 M6 x 12mm	9PCS
K		1PCS
M		8PCS
N		2PCS

Step1


AX 1

B X 2

G X 3

I X 3


K X 1



Step2

D X 1

E X 2



Step3

AX 1


B X 1

D X 1

FX 1

J X 1

K X 1



(screw tighten 80%)

Step4


C X 1

FX 3

J X 4

H X 1

K X 1



(screw tighten 80%)

Step5


C X 1

FX 3

J X 4


H X 1

K X 1



(screw tighten 80%)


Step6



(Make sure the accent chair is leveled on the ground.  
Then tighten all the screws by 100%)


Step7

M X 8



Step8

L X 4



WARNING: \*DO NOT STAND ON THE CHAIR \*THIS CHAIR IS DESIGNED TO SEAT ONE PERSON ONLY

\*DO NOT USE THE CHAIR UNLESS ALL THE BOLTS AND SCREWS ARE FINALLY TIGHTENED

\*AT LEAST EVERY FOUR MONTHS, PLEASE CHECK ALL BOLTS AND SCREWS TO MAKE SURE THEY ARE SECURELY TIGHTENED

\*IF ANY PARTS ARE MISSING, BROKEN, DAMAGED, OR WORN, STOP USING THIS PRODUCT IMMEDIATELY UNTIL REPAIRS ARE MADE

\*FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY