











CROSLEY
FURNITURE














Bookcase Hutch
CF3122



PARTS LIST

<div data-bbox="124 168 162 212">#A</div> 	<div data-bbox="400 168 438 212">#B</div> 	<div data-bbox="676 168 715 212">#C</div> 	<div data-bbox="952 168 991 212">#D</div> 	<div data-bbox="1228 168 1267 212">#E</div> 
Top Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Back Panel 1 PC	Fixed Shelf 1 PC
<div data-bbox="124 481 162 526">#F</div> 	<div data-bbox="400 481 438 526">#G</div> 	<div data-bbox="676 481 715 526">#H</div> 	<div data-bbox="952 481 991 526">#I</div> 	
Adjustable Shelf 1 PC	Back Bottom Rail 1 PC	Bracket 1 PC	Cover 1 PC	

HARDWARE LIST

<div data-bbox="124 848 162 893">#1</div> 	<div data-bbox="400 848 438 893">#2</div> 	<div data-bbox="676 848 715 893">#3</div> 	<div data-bbox="952 848 991 893">#4</div> 	<div data-bbox="1228 848 1267 893">#5</div> 
Shelf Holder 4 PCS (Extra 1)	Long Bolt 4 PCS (Extra 1) 1/4"*32mm	Short Bolt 8 PCS (Extra 1) 1/4"*12mm	Spring Washer 4 PCS (Extra 1) 1/4"*10mm	Flat Washer 4 PCS (Extra 1) 1/4"*13mm
<div data-bbox="124 1108 162 1153">#6</div> 	<div data-bbox="400 1108 438 1153">#7</div> 	<div data-bbox="676 1108 715 1153">#8</div> 	<div data-bbox="952 1108 991 1153">#9</div> 	<div data-bbox="1228 1108 1267 1153">#10</div> 
Wood Dowel 10 PCS (Extra 1) 8*30mm	Connecting Bar 2 PCS	Screw 8 PCS (Extra 1) 6*3*15mm	Round Head Screw 24 PCS (Extra 1) 8*3*15mm	Binding Post 1 SET (Extra 1)
<div data-bbox="124 1368 162 1413">#11</div> 	<div data-bbox="400 1368 438 1413">#12</div> 	<div data-bbox="676 1368 715 1413">#13</div> 		
Allen Wrench 1 PC M4	Small Allen Wrench 1 PC M2	Safety Strap Kit 1 SET		

ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver


Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Please do not use tools to assemble this unit unless specifically indicated.




Reference the images above any time the instructions state "lock the hardware"
Note: Be sure to check all hardware is locked when completed.



Step 1. Attach bracket (part H) to top panel (part A) using short bolts (part #3) and allen wrench (part #11).




- | | | |
|-----|---|-----|
| #3 |  | x 8 |
| #11 |  | x 1 |

Step 2. Attach cover (part I) to back panel (part D) using binding post (part #10) and small allen wrench (part #12).




#10		x 1
#12		x 1

Step 3. Attach fixed shelf (part E) and back bottom rail (part G) to right panel (part C) using wood dowels (part #6) and lock the hardware.




#6		x 3
----	---	-----

Step 4. Attach left panel (part B) to assembled unit (parts E & G) using wood dowels (part #6) and lock the hardware.




#6  x 3

Step 5. Attach top panel (part A) to assembled unit (parts B & C) using wood dowels (part #6) long bolts (part #2), spring washers (part #4), flat washers (part #5) and allen wrench (part #11).



#2		x 4
#4		x 4
#5		x 4
#6		x 4
#11		x 1


Step 6. Attach back panel (part D) to assembled unit (parts A, B, C, E & G) using round head screws (part #9) and phillips head screwdriver.



#9  x 24


Step 7. Carefully turn unit upright. Place shelf holders (part #1) into desired position and slide adjustable shelf (part F) into place.

Important: Safety strap kit (part #13) must be installed to prevent tipping, damage and/or injury.




#1  x 4

Step 8. Place hutch on base.









Step 9. Attach connecting bars (part #7) to top panel (part A) and back panel (part D) using screws (part #8) and phillips head screwdriver.

Important: Safety strap kit (part #13) must be installed to prevent tipping, damage and/or injury.



- | | | |
|----|---|-----|
| #7 |  | x 2 |
| #8 |  | x 8 |


#13	A	B	C	D	E
					
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Bracket 2 PCS	Short Screw 1 PC	Long Screw 1 PC	Safety Wall Strap 1 PC

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) and safety wall strap (E) through bracket (B) and attach to top panel (part A) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in top panel (part A) where bracket (B) is attached. Tap wall anchor (A) into the hole.
3. Insert long screw (D) and safety wall strap (E) through bracket (B) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING	
	Children have died from furniture tipover. To reduce the risk of furniture tipover:
	<ul style="list-style-type: none"> • ALWAYS install tipover restraint provided. • NEVER put a TV on this product. • NEVER allow children to stand, climb or hang on drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heaviest items in the lowest drawers.
This is a permanent label. Do not remove!	