Assembly Instructions - BM302287 (for DINING TABLE)

Please read instructions carefully


Remove all wrapping materials, staples and packing straps from the carton. Refer to Parts List and Hardware List and ensure they are complete before you start assembling. Place all wooden parts on a clean, flat and soft surface (e.g carpet or rug) to prevent parts from being scratched.

CAUTIONS:


- 1) DO NOT FULLY TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.
- 2) DO NOT OVER-TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.
- 3) KEEP ALL HARDWARE PARTS OUT OF REACH CHILDREN.

	PARTS LIST	Existing Qt y	Optional Qt y
P1	TABLE TOP	1	
P2	LEGS	4	
Р3	SUB-APRON	2	
P4	SUPPORT BAR	11	
P5	CENTER PANEL		1
P6	APRON of CENTER PANEL		2


	HARDWARE LIST		Existing Qty	Optional Qty
H1	M8 x 60mm JCBC SCREW	(magnificant)	8	
H2	M8 SPRING WASHER		8	
Н3	M8 FLAT WASHER	(0)	8	
H4	M5 ALLEN KEY		1	
H5	M6 x 35mm JCBC SCREW	THUMBUT (O	16	12
H6	M6 SPRING WASHER	9	12	6
H7	M6 FLAT WASHER	0	12	6
Н8	M4 ALLEN KEY		1	1



STEP 1




With a help of 2 or more adult people, carefully put you existing Table upside down on a clean, soft and flat surface. **Remove** the two pieces Sub-Aprons (P3) by unscrew Existing Bolts (H5) together Spring Washer (H6) & Flat Spring (H7) by using an allen key (H8).




STEP 2




Remove the other side of Sub-Aprons (P3) by unscrew Existing Bolts (H5) together Spring Washer (H6) & Flat Spring (H7) by using an allen key (H8).













H5 x 4 M6 x 35mm


Assemble both Apron (P6) into the Center Panel (P5) by aligning bolts (H5) Tighten the bolt using Allen Key (H8).





STEP 6 Attach the Center Panel (P5) between the existing Table tops, and pull the table top tightly before locking the latches.














CARE AND MAINTENANCE

SAFETY - To avoid any risk of suffocation to children and animals, dispose off plastic bags immediately.

CLEANING - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products.

FITTINGS - tighten bolts and nuts from time to time to ensure all parts of product are securely fitted.