We believe you will absolutely love your new furniture. Please immediately examine this product carefully. Any request for missing part or damage replacement must be received within 90 days of your receipt of the product. For some reason you want to return the product, please contact us directly before you decide to return your product to the retailer. Our Customer Service team can answer most concerns and can assist you with any questions you may have about your new product.

Please contact us first by emailing service@casepiece.com

Have these ready when you email:

- Item Number
- P0 #
- Purchaser Name
- Proof of Purchase
- Description of the problem and/or the Part Number needed

Replacements for missing or damaged parts or hardware are normally shipped within 3 to 5 business days and we thank you for your patient.

The item must be returned in good condition, in original box, with all original proof of purchase, parts and accessories, within the time frame specified by the retailer it was purchased from.

90-Day Limited Warranty Statement for Manufacturing Defects

Please read this Limited Warranty carefully. To maintain your Warranty, you will need to comply with the conditions stated here.

This warranty is for manufacturing defects only and does not cover damages as a result of misuse.

- 1. Our products sold comply with the description contained in this Warranty. All parts and products are warranted 90-Day from the original date of delivery except: parts and products used for commercial, contract, rental trade, institutional, or any other non-residential purposes; parts and products that have not been maintained in accordance with the care recommendations provided; parts and products damaged resulting from the consumer's improper assembly; or parts and products that are damaged or defective due to normal wear and tear.
- 2. To exercise rights under this warranty, proper documentation, i.e., photography, purchase order number, manufacturer's bar code label, and or any other pertinent information upon request is required. We reserve the right to repair or replace the product within the warranty period based upon the documentation received as support of a claim for consideration. We will not replace or repair any product if improper maintenance, improper handling, or improper use caused the damage. Any product sold from or modified by a Non-Authorized Dealer, Seller or Consumer will void the Warranty.
- 3. Cost of packaging and shipping to and from us is not covered by the warranty unless expressly arranged by us. This warranty does not extend to furniture that has been exchanged or replaced by us as settlement of an original claim of defective merchandise. This warranty does not extend to furniture that has been moved from delivery location on original purchase order.

We appreciate your business!


C90135DR-BN/DGY/LGY ASSEMBLY INSTRUCTION					
HARDWARES LIST					
ITEM	DESCRIPTION	DRAWING	QTY		
А	MINIFIX CAM LOCK		60 PCS		
В	MINIFIX CAM BOLT		60 PCS		
С	WOOD DOWEL (M6 x 25MM)		64 PCS		
D	WOOD DOWEL (M8 x 25MM)		4 PCS		
E	TRUSS M-SCREW (16MM)		12 PCS		
F	HANDLE		6 PCS		
G	6/8" NAIL		26 PCS		
н	PLASTIC STRIP (H SHAPE)		1 PC		
I	FLAT WASHER M6 x 19MM		4 PCS		
J	SPRING WASHER M6 x 13MM		4 PCS		
Please contact service@casepiece.com for assistance PAGE 2 OF					


C90135DR-BN/DGY/LGY ASSEMBLY INSTRUCTION					
HARDWARES LIST					
ITEM	DESCRIPTION	DRAWING	QTY		
К	CSK SCREW M4 x 20MM		2 PCS		
L	M4 ALLEN KEY (65MM)		1 PC		
М	JCBC SCREW M6 x55MM		4 PCS		
N	TIPPING RESTRAINT		1 PC		
0	CSK SCREW M4 x 16MM		4 PCS		

C90135DR-BN/DGY/LGY ASSEMBLY INSTRUCTION					
PARTS LIST					
ITEM	DESCRIPTION	DRAWING	QTY		
D1	TOP PANEL		1 PC		
D2	LEFT PANEL		1 PC		
D3	RIGHT PANEL		1 PC		
D4	CENTER PANEL		1 PC		
D5	SUPPORT RAIL	e e	2 PCS		
D6	FRONT TIPPING PANEL		2 PCS		
D7	BACK TIPPING PANEL		2 PCS		
D8	BACK PANEL		2 PCS		
D9	DRAWER HEAD		6 PCS		

C90135DR-BN/DGY/LGY ASSEMBLY INSTRUCTION					
PARTS LIST					
ITEM	DESCRIPTION	DRAWING	QTY		
D10	DRAWER BACK PANEL		6 PCS		
D11	DRAWER BOTTOM PANEL		6 PCS		
D12	BOTTOM PANEL		1 PC		
19	DRAWER LEFT PANEL		6 PCS		
20	DRAWER RIGHT PANEL		6 PCS		
21	DRAWER BOTTOM SUPPORT RAIL		6 PCS		
22	WOODEN LEG		4 PCS		
D24	CENTER LEG		1 PC		
*Note: All parts needed are shown in above picture					


*Note: All parts needed are shown in above picture. Numbers only indicate the specific parts for easy assembly.






STEP 2


NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.



STEP 3




STEP 4




C90135DR-BN/DGY/LGY ASSEMBLY INSTRUCTION STEP 5 STEP 6 NOTE : - Make sure arrows on each (A) point towards nearest edge with hole. <u>x 2</u>

STEP 7









C90135DR-BN/DGY/LGY ASSEMBLY INSTRUCTION STEP 9 INSIDE VIEW -No edge D6 STEP 10 INSIDE VIEW D6 No edge

C90135DR-BN/DGY/LGY ASSEMBLY INSTRUCTION STEP 11 INSIDE VIEW No edge D3 **D6** STEP 12 No edge D6 **D6** D12 INSIDE VIEW D2




STEP 14




STEP 15

Side with color paper must be the same.









STEP 17

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.




STEP 18





STEP 19

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.



STEP 20



