


ASSEMBLY INSTRUCTIONS

| PARTS # | PARTS NAME | DRAWING | QTY |
|---------|----------------|---|-----|
| Α | LEGS | ettti etti etti etti etti etti etti ett | 4 |
| В | PLASTIC WASHER | ₩ | 6 |
| С | HAEDREST | | 1 |






2. Take out Legs and plastic washer.



3. Screw in the legs



4. Level the chair and place it upright on a level surface. Please note: To level the chair, you may need to add or remove washers from the appropriate legs.

