
INSTRUCTION MANUAL



25" Wide Water and Stain Resistant Boucle Upholstered Accent Chair SKU: IA4003

(!) NOTICE

- ·Highly recommend immediate clean of the upholstery fabric although it is treated as water and stain repellent. Clean the chair with lukewarm water, mild detergent & soft cloth.
- ·Please do not exceed the weight limitation of this item. Do not stand on as a step ladder.
- ·Firmly secure all bolts before use. Reconfirm all bolts are secure every 90 days.
- ·Please adjust the speed slowly when you use electric drill for assembling to avoid screw slippage.
- •Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.

TOOLS REQUIRED



ALLEN WRENCH (PROVIDED)









HARDWARE





PARTS






PRODUCT ASSEMBLY

1

Attach 4pcs Part B Leg to Chair Bottom with 12pcs Hardware #1 Bolt.



2

Place the chair in normal position, sit on the seat and press downward till you feel the legs touch the ground evenly.

Tighten all bolts again.

Adjust feet levelers for perfect balance.

