

Product Name:	Children's Multi-Functional 3-Shelf Bookcase Toy Storage Bin, White
SKU #:	WHCF1872

Thank you for purchasing this LuxenHome product. This product has been manufactured with the highest standards of safety and quality.

PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.

Unpack all parts from the packaging inside the carton to ensure there are no missing or damaged parts. Do not attempt to assemble or use the product if any parts are missing or damaged.





Warning:


Products must be assembled by adults before being given to children. Products containing small parts, sharp edges and sharp points should be kept away from children during the non-assembly stage.

Do not climb, sit, or stand on this bookcase as this may damage the product and cause serious bodily harm. It is recommended that the adult check the product periodically to ensure all parts are tight and secure.

Do not climb, sit, or stand on this bookcase as this may damage the product and cause serious bodily harm. It is recommended that the adult check the product periodically to ensure all parts are tight and secure.

Hardware:

Ⓐ x12	Ⓑ x12	Ⓒ x24	Ⓓ x4	Ⓔ x4
		 M6x25	 M6x40	 M10x10
Ⓕ x21	Ⓖ x4	Ⓗ x4	Ⓘ x1	Ⓙ x1
 M4x10		 M4x30		
Ⓚ x6	Ⓛ x6	Ⓜ x4		
 M3x14				




Product Name:	Children's Multi-Functional 3-Shelf Bookcase Toy Storage Bin, White
SKU #:	WHCF1872

Panels:

① x1	② x1	③ x1	④ x1
⑤ x1	⑥ x1	⑦ x1	⑧ x3
⑨ x3	⑩ x1	⑪ x4	


Product Name:	Children's Multi-Functional 3-Shelf Bookcase Toy Storage Bin, White
SKU #:	WHCF1872

Panels:




Product Name:	Children's Multi-Functional 3-Shelf Bookcase Toy Storage Bin, White
SKU #:	WHCF1872

Step 1 – Attach hardware A on panel 1 & 2.




Step 2: Attach panel 3 to panel 2 by inserting into hardware B and locking in with hardware C.




Product Name:	Children's Multi-Functional 3-Shelf Bookcase Toy Storage Bin, White
SKU #:	WHCF1872

Step 3: Attach panels 8 to panels 4 & 5 by using hardware H.




Step 4: Attach panel 4 to panel 2 by inserting into hardware B and locking in with hardware C.




Product Name:	Children's Multi-Functional 3-Shelf Bookcase Toy Storage Bin, White
SKU #:	WHCF1872

Step 5: Attach panel 5 to panel 2 by inserting into hardware B and locking in with hardware C.





Ⓑ x2	Ⓒ x4

Step 6: Insert panel 6 between panels 4 & 5.





Product Name:	Children's Multi-Functional 3-Shelf Bookcase Toy Storage Bin, White
SKU #:	WHCF1872

Step 7: Insert hardware C into panels 2, 3, 4, 5 & 8.




Step 8: Attach panel 1 and insert hardware B to panel 2, 3, 4, 5 & 8.



!! Notice!!
Place top panel on the unit loosely,
do not tighten the fixings until step10


Product Name:	Children's Multi-Functional 3-Shelf Bookcase Toy Storage Bin, White
SKU #:	WHCF1872

Step 9: Insert panels 9 between paenl 1 & 2.




Step 10: Tighten all the hardware B.

!! Notice!!
Now tighten the fixings
to secure the top panel




Product Name:	Children's Multi-Functional 3-Shelf Bookcase Toy Storage Bin, White
SKU #:	WHCF1872

Step 11: Insert panel 7 between 1 & 2 from the bottom.




Step 12: Inserting hardware E to panel 1 & 2, attach panel 10 to the bottom by using hardware H and D.




Product Name:	Children's Multi-Functional 3-Shelf Bookcase Toy Storage Bin, White
SKU #:	WHCF1872

Step 13 Attach hardware G to panel 10 by using hardware F.




Step 14: Attach antislip stickers M on the bottom of legs 11. Screw in legs 11 into hardware G by hand. Attach hardware I on panel 4 by using hardware F.




Product Name:	Children's Multi-Functional 3-Shelf Bookcase Toy Storage Bin, White
SKU #:	WHCF1872

Step 15: To stabilize the bookshelf body, lock hardware L at the 6 corners of the bookshelf backboard with hardware K.




Step 16: Drill a hole in the wall by using electric drill.



Product Name:	Children's Multi-Functional 3-Shelf Bookcase Toy Storage Bin, White
SKU #:	WHCF1872

Step 17: For additional stability, secure the bookshelf to the wall using hardware H & J

(H) x1	(J) x1
	



Step 18

