
ASSEMBLY INSTRUCTIONS



Fine Furniture for every stage of life

Dining Table

PAGE 1 OF 4

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A TOP 1PC


B LEG 4PCS

C LEAF


HARDWARE IDENTIFICATION

1	BOLT (Φ5/16" x 65mm - RBW)	8PCS
2	LOCK WASHER (Φ5/16" - RBW)	8PCS
3	FLAT WASHER (Φ5/16" - RBW)	8PCS
4	ALLEN WRENCH (4MM - RBW)	1PC

ASSEMBLY INSTRUCTIONS STEP 1




STEP 2







ASSEMBLY INSTRUCTIONS STEP 3



STEP 4 COMPLETE







Note: Dimension tolerance ±5%