

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

701037 END TABLE

REVISION 0: 07/27/2023 REVISION 1: 01/24/2024

ITEM: 701037

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.

2. Please check to see that all hardware and parts are present prior to start of assembly.

3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION



NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:701037



HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 15g		1 PC	5	SCREW Ø4.5x42mm SR	AULIUU M	6 PCS
2	WOODEN DOWEL Ø8x30mm		16 PCS	6	STICKER		1 PC
3	CAM BOLT Ø7x35.5mm SR		4 PCS	7	SPACER SR		4 PCS
4	CAM LOCK Ø15x12mm SR		4 PCS	8	SCREW Ø4x15mm SR		16 PCS


NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:701037 **STEP 1 x** 16 E **INCORRECT** CORRECT Apply glue on all wooden dowels to ensure integrity of the structure. PAGE 4 OF 8 COASTERFURNITURE.COM

ITEM: **701037 STEP 2**









ITEM: **701037 STEP 4**












ITEM: **701037 STEP 6**








STEP 7 COMPLETE



ITEM: **701037**





Note: Dimension tolerance ±5%