ASSEMBLY INSTRUCTIONS



Fine Furniture for every stage of life

Loveseat

PAGE 1 OF 3

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A SEAT 1PC B LEFT ARM 1PC

C RIGHT ARM 1PC D BACK 1PC

E CROSSBAR 1PC F LEG 4PCS

HARDWARE IDENTIFICATION

1 PAN HEAD SCREW (4* 30mm - BLK)

Aurona

2PCS

2 FLAT WASHER (1/4"*16* 1.5mm - BLK




2PCS


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ASSEMBLY INSTRUCTIONS


STEP 1






STEP 3







Note: Dimension tolerance ±5%