









Product Assembly Instructions

CHANNELL DINING CHAIR



PART LIST

 <p>A : BACKREST x1</p>	 <p>B : BACK LEG x1</p>	 <p>C : SEAT CUSHION x1</p>
 <p>D : FRONT LEG (L &R) x2</p>		


HARDWARE LIST

 <p>E : JCBC SCREW M6 x 45mm x12</p>	 <p>F : SPRING WASHER 1/4" x12</p>	 <p>G : FLAT WASHER 1/4" x8</p>
 <p>H : M4 ALLEN KEY (BALL SHAPE) LONG x1</p>		


STEP 1



STEP 2



STEP 3



STEP 4

