


INSTRUCTIONS


Note:

1. Please make sure that the electricity is powered off during installation!
2. Only a professional electrician should install this kind of products!




1. Drill a hole with impact bit machine at the ceiling, hit the expansion anchor into the hole with hammer, rotate to install the ceiling hook to the anchor.


2. Hang the shock cord hook to the ceiling hook.




3. Let the wire go through the open side of shock cord hook, adjust suitable distance of the wire.



4. Install the lampshade to the fixture with socket ring.









INSTRUCTIONS



dimmmable switch

should use the bulb which could be dimmable or with dimmable function, such as E26 incandescent bulb or dimmable LED bulb.



A		3PCS	B		3PCS	C		2PCS
D		1PCS	E		1PCS			