



ITEM NAME / NOM D'ITEM: SHORELINE ACCENT CHAIR


ITEM # / NO.ITEM: 704042

PARTS LIST / LISTE DES PIÈCES


(1)	(2)
 ×1	 ×1

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE

I



II



Please use the attached adjustable footglides to level the chair on uneven surface.