

**W**e believe you will absolutely love your new furniture. Please immediately examine this product carefully. Any request for missing part or damage replacement must be received within 90 days of your receipt of the product. For some reason you want to return the product, please contact us directly before you decide to return your product to the retailer. Our Customer Service team can answer most concerns and can assist you with any questions you may have about your new product.

Please contact us first by emailing [service@casepiece.com](mailto:service@casepiece.com)

Have these ready when you email:

- Item Number
- PO #
- Purchaser Name
- Proof of Purchase
- Description of the problem and/or the Part Number needed

Replacements for missing or damaged parts or hardware are normally shipped within 3 to 5 business days and we thank you for your patient.

The item must be returned in good condition, in original box, with all original proof of purchase, parts and accessories, within the time frame specified by the retailer it was purchased from.

## 90-Day Limited Warranty Statement for Manufacturing Defects

Please read this Limited Warranty carefully. To maintain your Warranty, you will need to comply with the conditions stated here.

This warranty is for manufacturing defects only and does not cover damages as a result of misuse.

1. Our products sold comply with the description contained in this Warranty. All parts and products are warranted 90-Day from the original date of delivery except: parts and products used for commercial, contract, rental trade, institutional, or any other non-residential purposes; parts and products that have not been maintained in accordance with the care recommendations provided; parts and products damaged resulting from the consumer's improper assembly; or parts and products that are damaged or defective due to normal wear and tear.











2. To exercise rights under this warranty, proper documentation, i.e., photography, purchase order number, manufacturer's bar code label, and or any other pertinent information upon request is required. We reserve the right to repair or replace the product within the warranty period based upon the documentation received as support of a claim for consideration. We will not replace or repair any product if improper maintenance, improper handling, or improper use caused the damage. Any product sold from or modified by a Non-Authorized Dealer, Seller or Consumer will void the Warranty.

3. Cost of packaging and shipping to and from us is not covered by the warranty unless expressly arranged by us. This warranty does not extend to furniture that has been exchanged or replaced by us as settlement of an original claim of defective merchandise. This warranty does not extend to furniture that has been moved from delivery location on original purchase order.

We appreciate your business!










# C7052 HT-DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION

## HARDWARES LIST

ITEM	DESCRIPTION	DRAWING	QTY
A	MINIFIX CAM LOCK		54 PCS
B	MINIFIX CAM BOLT		54 PCS
C	WOOD DOWEL M8X25MM		22 PCS
D	CSK SCREW M3.5X15MM		8 PCS
E	6/8" NAIL		56 PCS
F	HOOK		4 PCS
G	PLASTIC STRIP (H SHAPE)		2 PCS
H	SHELF SUPPORT		12 PCS
I	STICKER		28 PCS
J	TIPPING RESTRAINT		1 PC







# C7052 HT- DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION

## PART LIST

ITEM	DESCRIPTION	DRAWING	QTY
1	TOP PANEL		1 PC
2	TOP LEFT PANEL		1 PC
3	TOP RIGHT PANEL		1 PC
4	TOP SHELF PANEL		1 PC
5	TOP SUPPORT PANEL		1 PC
6	BOTTOM SUPPORT PANEL		1 PC
7	TOP BACK PANEL		3 PCS
8	BENCH TOP PANEL		1 PC
9	BENCH LEFT & RIGHT PANEL		2 PCS


# C7052 HT-DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION

## PARTS LIST


ITEM	DESCRIPTION	DRAWING	QTY
10	CENTER PANEL		2 PCS
11	BENCH SHELF PANEL		3 PCS
12	BOTTOM PANEL		1 PC
13	LEG FRAME (LONG)		2 PCS
14	LEG FRAME (SHORT)		3 PCS
15	BOTTOM BACK PANEL		1 PC

### ASSEMBLY TOOLS REQUIRED

#### 1. Screwdriver (not provide)




#### 2. Hammer (not provide)




# C7052 HT-DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION

NOTE : - The outer board is for protection of packaging only, not part of furniture. Please throw it before assembly.




## STEP 1



# C7052 HT-DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION


## STEP 2

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.



## STEP 3


NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.



# C7052 HT-DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION


## STEP 4

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.



## STEP 5


NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.




# C7052 HT-DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION

## STEP 6

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.




## STEP 7






# C7052 HT- DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION

## STEP 8




## STEP 9




# C7052 HT- DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION

## STEP 10




## STEP 11

Side with color paper must be the same




## STEP 12



## STEP 13

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.

**x 2**




# C7052 HT-DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION


## STEP 14

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.

**x 2**



## STEP 15




# C7052 HT- DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION

## STEP 16

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.


**x 2**



## STEP 17


NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.

**x 3**




# C7052 HT-DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION

## STEP 18




## STEP 19




# C7052 HT- DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION

## STEP 20




## STEP 21




# C7052 HT-DGY/LGY/BN/BK/WT ASSEMBLY INSTRUCTION

## STEP 22




## STEP 23





STEP 24







## STEP 25



### CAUTION

This step requires second adult's assistance to avoid injury or product damage.



STEP 26

