











ITEM NAME / NOM D'ITEM: NIDA DINING TABLE


ITEM # / NO.ITEM: 109957

PARTS LIST / LISTE DES PIÈCES


(1)	(2)	(3)	(4)
 ×1	 ×2	 ×2	 ×1
(5)			
A. M6 x 30MM  x14	B. M8 x 30MM  x4	C. Ø6MM  x14	
D. Ø6MM  x14	E. 5MM  x1	F. 4MM  x1	

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE


I




II



III



IV



Please use the attached adjustable footglides to level the table on uneven surface.

For missing parts or damaged parts, please call /
Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico : (866)798-6663

AI-V1-240618