











ITEM NAME / NOM D'ITEM: KANI DINING TABLE


ITEM # / NO.ITEM: 110360

## PARTS LIST / LISTE DES PIÈCES


(1)	(2)	(3)
		
x1	x2	x2
(4)		
A. M6 x 20MM  x8	D. Ø8MM  x10	G. 4MM  x1
B. M8 x 30MM  x10	E. Ø8MM  x4	
C. Ø8MM  x10	F. 5MM  x1	

## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE


I



II



III



Please use the attached adjustable footpads to level the chair on uneven surface.

For missing parts or damaged parts, please call /  
Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico : (866)798-6663

AI-V1-240513