

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

123119 <u>Counter Stool</u>

REVISION 0: 11/15/2023

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM: 123119

ASSEMBLY INSTRUCTIONS

COASTER

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	BACK FRAME	1PC
В	SEAT CUSHION WITH FRAME	1PC
С	LEFT FRONT LEG	1PC
D	RIGHT FRONT LEG	1PC
E	FRONT STRETCHER	1PC
F	LEFT SIDE STRETCHER	1PC
G	RIGHT SIDE STRETCHER	1PC

HARDWARE IDENTIFICATION

1	LONG BOLT (Ø5/16" x 76mm - RBW)	(a)—))))))))))	4PCS
2	MEDIUM BOLT (Ø5/16" x 50mm- RBW)		4PCS
3	SHORT BOLT (Ø5/16" x 38mm - RBW)	(a)	2PCS
4	LOCK WASHER (Ø5/16" *1.5mm - RBW)		10PCS
5	FLAT WASHER (Ø5/16" *2mm - RBW)	0	10PCS
6	PAN HEAD SCREW (Ø4* 38mm - RBW)	() யைய	6PCS
7	ALLEN WRENCH (Ø4* 58mm- RBW)		1PC

NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 123119


ASSEMBLY INSTRUCTIONS

STEP 1






STEP 2




STEP 3 COMPLETE





ITEM:123119





Note: Dimension tolerance ±5%