


ITEM NAME / NOM D'ITEM: SERASA DINING CHAIR

ITEM # / NO.ITEM: 109978

NO ASSEMBLY REQUIRED



Please use the attached adjustable footglides to level the chair on uneven surface.