

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

181378 Counter Stool

REVISION 0: 09/26/2023

PAGE 1 OF 4

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

Α	BACKREST	1PC
В	SWIVEL PLATE WITH FRAME	1PC
С	UPPER LEG	1PC
D	LOWER LEG	1PC
E	FOOTREST	1PC
F	SEAT CUSHION	1PC

HARDWARE IDENTIFICATION

1	BOLT (M6 x45MM - BLK)	14PCS
2	LOCK WASHER (1/4" - BLK)	14PCS
3	FLAT WASHER (1/4"x 16MM - BLK)	10PCS
4	FLAT HEAD SCREW (M4 x 32MM - BLK)	4PC
5	ALLEN WRENCH (M4 x 65MM - BLK)	1PC

NOTE:


Quantities shown are for one stool.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ASSEMBLY INSTRUCTIONS

COASTER


STEP 1



STEP 2



STEP 3




PAGE 3 OF 4

COASTERFURNITURE.COM


COASTER'

ASSEMBLY INSTRUCTIONS

STEP 4




STEP 5 COMPLETE









Note: Dimension tolerance $\pm 5\%$