


Installation sequence

1




OFF

STEPS1

Turn off the power


2



STEPS2

Let the wire go through the lampshade and canopy, rotate to fix both parts to the fixture.


3



STEPS3

Install the bracket to the ceiling junction box with screw.

4




black L
white N
Earth E

STEPS4

1.Connect the power cord of the fixture to the reserved power supply cable, pay attention to the positive and negative poles.
2.Install the fixture to the bracket with cap nuts.


5



Suggest to use G45 Ping-pong bulb!

STEPS5

Install the bulb.



Before installation, please check whether the accessories are completed. If there is any problem, please contact our customer service team.

Note:

- 1.Voltage: 120V-60Hz
- 2.Bulb type: E26 / MAX-60W
- 3.Before installation, please cut off the power supply to prevent eletricity shock.
- 4.Please be sure the installation steps according to the instructions.