
ASSEMBLY INSTRUCTION



Thank you for purchasing this product. Please take time to read and follow instructions below. Check that you have all parts and hardware before assembly. Parts apparently missing are often found in packing matterials. If you do not have all parts listed, call us and they be sent to you immediately




It is recommended to install protective pads under all legs and supports to avoid damage or scratches when placing furniture on a wood floor or other hard surface, and to limit indentation and prevent discoloration if placing on carpet.

PARTS LIST					
NO.	SKETCH	DESCRIPTION	Q'TY		
A	\Diamond	WOODEN SEAT	1PC		
В	Ã	LEG	2PCS		
С		STRETCHER	2PCS		


HARDWARE LIST						
NO.	DESCRIPTION	SIZE	SKETCH	Q'TY		
1	BOLT	Ø1/4" x 40mm		4PCS		
2	LOCK WASHER	Ø1/4"	0	4PCS		
3	FLAT WASHER	Ø1/4"x 3/4"	0	4PCS		
4	ALLEN KEY	1/6" x 2-1/4"		1PC		
5	WOOD SCREW	#4*50mm	Chimina	4PCS		

**SCREW DRIVER(NOT PROVIDED)






Step 2




Page 1 of 2

ASSEMBLY INSTRUCTION

Step 3



Step 4



DO NOT TIGHTEN BOLTS UNTIL COMPLETELY ASSEMBLED.