
Item Number: 43834952/ 43834921

WARNING (To reduce the risk of fire, electric shock, or personal injury):


- 1. We suggest installation by a licensed electrician.
- 2. Please read the instruction carefully and save it as you may need it at a later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done.
 - **»** Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "**OFF**" position.
 - » Place the wall switch in the "OFF" position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all sides. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before installation.
- 6. Make sure the voltage you are using is 120V. The maximum wattage is Type B, Max 40W per bulb.
- 7. Keep the lamp away from acidic and alkaline substances in case of damaging the surface of the lamp.
- 8. When replacing bulbs, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- 9. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.


IMAGE FOR FINISHED PRODUCT:



TOOLS REQUIRED (NOT INCLUDED):

Before starting assembly and installation please prepare the needed tools as below picture






ASSEMBLY & INSTALLATION INSTRUCTIONS:


- 1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration.
- 2. Turn off power


Before you start the installation, NEVER attempt any work without shutting off the electricity until the work is done.

- **»** Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "**OFF**" position.
- » Place the wall switch in the "OFF" position.
- 3 » Unscrew ball knobs (H) from canopy (E) then gently remove mounting plate (A).




- 4 » 1) To adjust the hanging height of the fixture:
 - Press down and hold lock nut (F) by hand.
 - Pull or push steel wires (I) in and out of canopy (E) to increase or decrease the hanging height.
 - 2) To adjust the length of cable (J):
 - Use screwdriver to unscrew the screw in one of strain relief (G) as shown in the illustration.
 - Carefully pull and push cable (J), then tighten the screw till snug.
 - 3) After adjusting the height of the fixture, to adjust insurance buckles (O):
 - Use a wrench to loosen insurance buckles (O), and then pull insurance buckles (O) to the bottom of canopy by hand.
 - Tighten insurance buckles (O) with a wrench to prevent body from sliding off as shown in the illustration below.





5 » Carefully pass supply wires through mounting plate (A). Secure mounting plate (A) to the outlet box with mounting screws (D).


> NOTE: the side of mounting plate (A) marked "GND" must face out.



6 » Make wire connections

Connect wires as shown in the charts below. PLEASE NOTE THAT GROUND WIRE IS BARE COPPER WIRE, NEVER CONNECT OTHER WIRES TO GROUND WIRES.

Connect ground wires according to the chart below




Connect wires according to the chart below	
Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
Black	White
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer
Insulated wire(other than green) with copper conductor	Insulated wire(other than green) with silver conductor
* Note: When parallel wires (SPT I& SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in shape or smooth (see illus.) Neutral Wire	

- Twist wires together with plastic wire connector until tightly joined.
- Wrap each connector with approved electrical tape for a more secure connection.
- Carefully tuck all wires into the outlet box.
- 7 » 1) Open quick link (P), and then hang it onto the mounting plate (A) as shown in the illustration.
 - 2) Fix canopy (E) to mounting plate (A) and secure with the previously removed ball knobs (H).

Note: canopy (E) should be snug against the ceiling and ball knobs (H).

If not, adjust the threaded length of the preassembled mounting screws on mounting plate (A):


- first, unscrew the pre-assembled hex nuts;
- then, screw the pre-assembled mounting screws in or out of mounting plate (A);
- when the secure length is achieved, tighten the pre-assembled hex nuts and back to step 7.





• Loose crystal screws (L) behind crystals (N), and then adjust crystals (N) to the right place. Tighten crystal screws (L) with Allen wrench (K) as shown in the illustration.

Install bulbs (Not included) (Please do not exceed the maximum wattage recommended on the socket.)



9. Check that everything is installed properly, then you can turn on the light. We hope you enjoy your new lighting!

ORDERING PARTS

Keep this sheet for future reference in case you need to order replacement parts. All parts for this fixture can be ordered from the place of purchase. Be sure to use exact wording from illustration when ordering parts.

CLEANING

To clean, wipe the fixture with a soft cloth. Clean glass with a mild cleaner (such as mild and non-abrasive soap). Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.