


Item Number: 43834945

WARNING (To reduce the risk of fire, electric shock, or personal injury):

- 1. We suggest installation by a **licensed electrician**.
- 2. Please read the instruction carefully and save it as you may need it at a later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done.
 - » Go to the main fuse, or circuit breaker, box in your home.
Place the main power switch in the **“OFF”** position.
 - » Place the wall switch in the **“OFF”** position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4” larger than the canopy on all sides. Any gaps between the mounting surface and canopy exceeding 3/16” should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before installation.
- 6. Make sure the voltage you are using is **120V**. The maximum wattage is **Type B, Max 40W** per bulb.
- 7. Keep the lamp away from acidic and alkaline substances in case of damaging the surface of the lamp.
- 8. When replacing bulbs, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- 9. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

IMAGE FOR FINISHED PRODUCT:



ORDERING PARTS






Keep this sheet for future reference in case you need to order replacement parts. All parts for this fixture can be ordered from the place of purchase. Be sure to use exact wording from illustration when ordering parts.

CLEANING

To clean, wipe the fixture with a soft cloth. Clean glass with a mild cleaner (such as mild and non-abrasive soap). Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

**TOOLS REQUIRED
(NOT INCLUDED):**

Before starting assembly and installation please prepare the needed tools as below picture


| | | | | |
|---|---|---|--|---|
|  |  |  |  |  |
| Ladder | Philips Head or Flat Blade Screwdriver | Electrical Tape | Pliers | Wire Cutter/Stripper |

PARTS TYPE & QTY INCLUDING:

- (C) Mounting plate (1)
- (D) Green ground screw (1)
- (E) Canopy (1)
- (F) Lock nut (3)
- (G) Strain relief (1)
- (H) Ball knob (2)
- (I) Steel wire (3)
- (J) Cable (1)
- (K) Screw (3)
- (L) Upper body (1)
- (M) Bottom body (1)

ACCESSORIES & QTY ENCLOSED:

- (A) Plastic Wire Connector (3)
- (B) Mounting screw (2)
- (N) Crystal (1) (spare part)
- (O) Crystal hook (5) (spare part)
- (P) Allen wrench (1)




ASSEMBLY & INSTALLATION INSTRUCTIONS:


1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration.
2. Turn off power
Before you start the installation, **NEVER** attempt any work without shutting off the electricity until the work is done.

- » Go to the main fuse, or circuit breaker, box in your home.
Place the main power switch in the **"OFF"** position.
- » Place the wall switch in the **"OFF"** position.


- 3 » Unscrew ball knobs (H) from canopy (E) then gently remove mounting plate (C).




- 4 » Align holes of bottom body (M) and holes of upper body (L), and then screw screws (K) into holes to secure bodies as shown in the illustration.



- 5 » 1) To adjust the hanging height of the fixture:
- Press down and hold lock nuts (F) by hand.
 - Pull or push steel wires (I) in and out of canopy (E) to increase or decrease the hanging height.
- 2) To adjust the length of cable (J):
- Use Allen wrench (P) to unscrew the screw in strain relief (G) as shown in the illustration.
 - Carefully pull and push cable (J), then tighten the screw till snug.




- 6 » If needed, shorten the length of fixture wires. At this point, the remaining wire length measured above mounting plate (C) is at least 6".



- 7 » Carefully pass supply wires through mounting plate (C).
Secure mounting plate (C) to the outlet box with mounting screws (B).


NOTE: the side of mounting plate (C) marked "GND" must face out.



8 » Make wire connections

Connect wires as below wires connection shown. **REFER TO THE FOLLOWING CHARTS, NEVER CONNECT OTHER WIRES TO GROUND WIRES.**

Connect ground wires according to the below chart



Connect wires according to the below chart

| Connect Black or Red Supply Wire to: | Connect White Supply Wire to: |
|---|---|
| Black | White |
| *Parallel cord (round & smooth) | *Parallel cord (square & ridged) |
| Clear, Brown, Gold or Black without tracer | Clear, Brown, Gold or Black with tracer |
| Insulated wire (other than green) with copper conductor | Insulated wire (other than green) with silver conductor |

* Note: When parallel wires (SPT I & SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in shape or smooth (see illus.)

Neutral Wire


Twist wires together with plastic wire connectors until tightly joined.
Wrap each connector with approved electrical tape for a more secure connection.
Carefully tuck all wires into the outlet box.

9 » Fix canopy (E) to mounting plate (C) and secure with the previously removed ball knobs (H).


Note: canopy (E) should be snug against the ceiling and ball knobs (H).

If not, adjust the threaded length of the pre-assembled mounting screws on mounting plate (C):

- First, unscrew the pre-assembled hex nuts.
- Then, screw the pre-assembled mounting screws in or out of mounting plate (C).
- When the secure length is achieved, tighten the pre-assembled hex nuts and back to step 9.



10 » Install bulbs (Not included) (Please do not exceed the maximum wattage recommended on the socket.)



11. Check everything is already installed properly, then you could turn on the light. Enjoy!