












# ASSEMBLY INSTRUCTION

Thank you for purchasing this product. Please take time to read and follow the instruction below. Check that you have all parts and hardware before assembly. Parts apparently missing are often found in the packing materials. If you do not have all the parts listed,have your dealer contact us and they will be sent to you immediately.


 It is recommended to install protective pads under all legs and support to avoid damage or scratches when placing furniture on a wood floor or other hard surface, and to limit indentation and prevent discoloration if placing on carpet.

PARTS LIST				HARDWARE LIST			
A		Chair	1	G		Bolt 5/16"-18 x 1 - 3/4"	8
B		Seat Cushion	1	H		Spring Washer 5/16"x11/32"x1/2"x1/16"	8
C		LSF Front Leg	1	I		Flat Washer 5/16"x11/32"x3/4"x1/16"	8
D		RSF Front Leg	1	J		Allen Key 5/32"	1
E		LSF/RSF Rear Leg	2				
F		Black Woven Dust Cover	1				


## STEP 1




## STEP 2




## STEP 3



## STEP 4



## COMPLETED



### CARE INSTRUCTION FOR FABRIC FURNITURE

In order to maintain the original appearance of your fabric furniture, please follow below care procedures:

- . Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and / or exposure to heating and air conditioning outlets will fade/damage fabric. Do not place your upholstered furniture too close to windows, radiators, or vents and be sure to use window treatments to block the sun's rays.
- . Use soft brush to remove dust.