



ASSEMBLY INSTRUCTIONS



www.artleon.com


Email: hello@artleon.com

12770 Moore St Cerritos CA 90703


SPARE PARTS



Ax1



Bx1



Cx4
M6x18mm



Dx1

Be sure to keep spare parts.

If screws or nails of a product are damaged or lost,
or screws or nails of a subsequent product are
damaged or aged, spare parts can be used to replace them.

1



Ax1



Bx1



Cx4



Dx1

