


- Please check your product packaging to make sure the included accessories are in the "list of standard accessories". If any parts are missing, please contact your local dealer immediately.
- Do not allow any sharp objects to come in contact with the cabinet, as it will scratch the surface.
- •Continuous and prolonged exposure to direct sunlight may cause discoloration to the wood.
- Do not put any hot appliances directly on or near the cabinet.
- •Please avoid using cleaning products that contain bleach or ammonia.
- Wood surfaces should only be cleaned with wood care products such as soapy water or furniture polish.

MODEL: EVVN412-78WH/GR/ES



INSTALLATION



MAIN BODY PARTS






INSTALLATION PARTS



ERECTING TOOL



DRAWER'S ADJUST



INSTALLATION INSTRUCTIONS

