








Installation Instruction


SKU:BSC115

				
Dining chair×1	Swivel wheel×4 (Assembled)	Phillips Screwdriver×1	Long Leg×4	Plastic washer×5 (1 spare)

Step 1:



Attention: The dining chair offers interchangeable fixed plastic legs and swivel wheels for optional mobility. If mobility is not needed, simply replace the wheels with the included plastic legs. Each chair is equipped with four plastic legs and five plastic washers—one provided as a spare.



depending on your desired height.

