



ITEM NAME / NOM D'ITEM: RAHAT ACCENT CHAIR
ITEM # / NO.ITEM: 110294

PARTS LIST / LISTE DES PIÈCES

(1)	(2)	(3)
 ×1	 ×4	A. Ø45MM  ×4


ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE

I


Remove (2) from pouch first

(2)

(Bottom)



II



Please use the attached adjustable footglides to level the chair on uneven surface.