




ITEM NAME / NOM D'ITEM: BIAK CORNER CHAIR
ITEM # / NO.ITEM: 110366


PARTS LIST / LISTE DES PIÈCES

(1)	(2)	(3)
 ×1	 ×4	A. Ø45MM  ×4

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE


I

Remove (2) from pouch first



(Bottom)

II



Please use the attached adjustable footglides to level the chair on uneven surface.

Optional

(110366) → ← (110367)

