





Installation Instruction

SKU:BSC116

			
Dining Chair×1	Phillips Screwdriver×1	Long Leg×4	Flat Washer×9
			
Spring Washer×9	Swivel Wheel×4 (Assembled)	Plastic Washer×5 (1 spare)	

Step 1 :



Attention: The dining chair offers interchangeable fixed plastic legs and swivel wheels for optional mobility. If mobility is not needed, simply replace the wheels with the included plastic legs. Each chair is equipped with four plastic legs and five plastic washers—one provided as a spare.

