


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

551464 *Armless Chair*

ITEM:551464



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES


PARTS IDENTIFICATION

Α	BODY FRAME	1PC
В	BACK CUSHION	1PC
С	SEAT CUSHION	1PC
D	LEG	4PCS


ITEM:**551464**




ASSEMBLY INSTRUCTIONS STEP 1



STEP 2





STEP 3 COMPLETE



ITEM:**551464**







Note: Dimension tolerance ±5%

COASTERFURNITURE.COM