



ASSEMBLING INSTRUCTION


Ax4



Ex1





1




2

Remove cap
from tip of gas lift.




Bx1



Fx1



Cx1



Gx1



3



Dx1

