

Daily-care Note

1. Please cover the conversation sets with a water-proof cover when not in use, otherwise the surface will be dirty and the cushion will be damaged due to water absorption.
2. When cleaning the cushion, please remove the sponge inside the cushion. Try to choose manual cleaning instead of washing in a washing machine.
3. When cleaning the surface and metal frame of the wicker chair, please wipe it with clean water. It is not recommended to use other cleaning agents to wipe to prevent discoloration or damage to the surface.