


sku:HZ-KFS0102/HZ-KFS0103

Steel wicker sofa set



Thank you for choosing us!

Our goal is to provide high quality outdoor furniture with outstanding customer service-all at an affordable price.

Please let us know how we are doing!



Tip: We recommend flattening the boxes to use as a protective work surface, or setting up your new furniture on a soft floor like a carpet.



**IMPORTANT, RETAIN FOR
FUTURE REFERENCE:
READ CAREFULLY.**

Safety

- ☒ For domestic use only.
- ☒ Always use on firm level ground.
- ☒ Don't tighten all the bolts before the product is fully assembled.
- ☒ It would be useful to ask someone to help you assemble the product.
- ☒ Periodic structural checks of this product should be undertaken, do not use if you have any doubts about its fitness for purpose.
- ☒ Do not stand on the seat.
- ☒ Do not let children play with this product.
- ☒ Maximum load per seat: 250 lbs.

At the beginning of the season



- ☒ Check to ensure that all components and fixings of this product are secure, do not use if you have any doubts about its fitness for purpose.

At the end of the season


- ☒ This product should be stored under cover during prolonged spells of adverse weather (wet or cold) and also during the winter (ideally in a garden shed or garage).
- ☒ Always clean and dry thoroughly before storage.

How to Put on the Cushion Cover

1




OR




1.Take the cushion covers and inners out of the carton.

2




2.Fold the inner in half, pushing the sides together, then begin to slide the cover onto it.

3




3.Align both far corners, then gently compress insert while fitting cover around it.

4



4.To avoid a stuck zipper, please pull the fabric away from the zipper before moving forward.

5



5.When all done, please pat the cushion or give it a little shake to make it more flat.

Care & Cleaning Guidelines

The covers are machine washable. Before washing, please zip the cover up to avoid catching other clothes. You can clean the dust on the chair / table / footstool with a damp cloth.


IMPORTANT

Please make a decision which model you want to put modules together, because you have to use different parts to make it either a corner sofa or an armless sofa.

Option 1: Seat Base(B)+Back Panel(A)+Back Panel(E), can be assembled as the corner sofa, then you can put them together as corner sofa set model (Figure A).


Option 2 Seat Base(B)+Back Panel(A)+Side Panel (C) can be assembled as the third armless sofa, then you can put them together as living sofa set model(Figure B).

Option 1

















6 Pcs Corner Sofa Model

Option 2



6 Pcs Living Sofa Model

COMPONENT LIST - ARMLESS SOFA X 2

Item no.	Reference Image	Description	Qty.
A		Back Panel	1
B		Seat Base	1
C		Side Panel	1
O		High L-Shaped Feet	4
P		Screw Feet	4
Q		M6*45 Head Cap Screw	4
S		M6*30 Head Cap Screw	3
L		M6*25 Head Cap Screw	8
V		Wrench	1
W		Allen Key	1
Z		Seat Cushion Foam	1
Y		Long Back Cushion	1
R		Nut	4
T		Washer	11



NOTE:

Do NOT tighten any screws fully first until you have tightened all the screws.

This may cause the frame to warp.

If there is still wobbles or screw holes cannot be aligned, loosen the screws and tighten sequentially.

If the Sofa is not stable it could lead to damage to the product.

01**Q****M6*45 Screw ×3****R****Nut ×3****T****Washer ×6**

NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

02

Q



M6*45 Screw ×1

S



M6*30 Screw ×3

R




Nut ×1

T



Washer ×5







NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

03

(L)




M6*25 Screw x8
















NOTE:IF ANY SCREW HOLES CANNOT BE ALIGNED, LOOSEN ALL THE SCREWS AND GO BACK STEP 1 AND RESTART ASSEMBLY.

04



COMPONENT LIST - LEFT CORNER SOFA

Item no.	Reference Image	Description	Qty.
A		Back Panel	1
B		Seat Base	1
D		Armrest	1
O		High L-Shaped Feet	4
P		Screw Feet	4
Q		M6*45 Head Cap Screw	7
L		M6*25 Head Cap Screw	8
V		Wrench	1
W		Allen Key	1
Z		Seat Cushion Foam	1
Y		Long Back Cushion	1
R		Nut	7
T		Washer	14



NOTE:

Do NOT tighten any screws fully first until you have tightened all the screws.

This may cause the frame to warp.

If there is still wobbles or screw holes cannot be aligned, loosen the screws and tighten sequentially.

If the Sofa is not stable it could lead to damage to the product.

01**Q****M6*45 Screw ×3****R****Nut ×3****T****Washer ×6**

NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

02

Q



M6*45 Screw x4

R





Nut x4

T



Washer x8







NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

03

(L)




M6*25 Screw ×8
















NOTE:IF ANY SCREW HOLES CANNOT BE ALIGNED, LOOSEN ALL THE SCREWS AND GO BACK STEP 1 AND RESTART ASSEMBLY.

04



COMPONENT LIST - RIGHT CORNER SOFA

Item no.	Reference Image	Description	Qty.
A		Back Panel	1
B		Seat Base	1
D		Armrest	1
O		High L-Shaped Feet	4
P		Screw Feet	4
Q		M6*45 Head Cap Screw	7
L		M6*25 Head Cap Screw	8
V		Wrench	1
W		Allen Key	1
Z		Seat Cushion Foam	1
Y		Long Back Cushion	1
R		Nut	7
T		Washer	14



NOTE:

Do NOT tighten any screws fully first until you have tightened all the screws.

This may cause the frame to warp.

If there is still wobbles or screw holes cannot be aligned, loosen the screws and tighten sequentially.

If the Sofa is not stable it could lead to damage to the product.

01**Q****M6*45 Screw ×3****R****Nut ×3****T****Washer ×6**

NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

02

Q



M6*45 Screw ×4

R





Nut ×4

T



Washer ×8






NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

03

(L)




M6*25 Screw x8

















NOTE:IF ANY SCREW HOLES CANNOT BE ALIGNED, LOOSEN ALL THE SCREWS AND GO BACK STEP 1 AND RESTART ASSEMBLY.

04



COMPONENT LIST - CORNER SOFA

Item no.	Reference Image	Description	Qty.
A		Back Panel	1
B		Seat Base	1
E		Back Panel	1
O		High L-Shaped Feet	4
P		Screw Feet	4
Q		M6*45 Head Cap Screw	8
L		M6*25 Head Cap Screw	8
V		Wrench	1
W		Allen Key	1
Z		Seat Cushion Foam	1
Y		Long Back Cushion	1
Y1		Short Back Cushion	1
R		Nut	8
T		Washer	16



NOTE:

Do NOT tighten any screws fully first until you have tightened all the screws.

This may cause the frame to warp.

If there is still wobbles or screw holes cannot be aligned, loosen the screws and tighten sequentially.

If the Sofa is not stable it could lead to damage to the product.

01**Q****M6*45 Screw ×3****R****Nut ×3****T****Washer ×6**

NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

02

Q



M6*45 Screw ×5

R





Nut ×5

T



Washer ×10






NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

03

(L)




M6*25 Screw ×8














NOTE:IF ANY SCREW HOLES CANNOT BE ALIGNED, LOOSEN ALL THE SCREWS AND GO BACK STEP 1 AND RESTART ASSEMBLY.

04



COMPONENT LIST -TABLE

Item no.	Reference Image	Description	Qty.
H		Side Panel	2
I		Side Panel	2
K		Table Connector	1
O		High L-Shaped Feet	4
P		Screw Feet	4
S		M6*30 Head Cap Screw	12
L		M6*25 Head Cap Screw	8
V		Wrench	1
W		Allen Key	1
G		Glass	1
T		Washer	12



NOTE:

Do NOT tighten any screws fully first until you have tightened all the screws.

This may cause the frame to warp.

If there is still wobbles or screw holes cannot be aligned, loosen the screws and tighten sequentially.

If the Table is not stable it could lead to damage to the product.

01**(S)****M6*30 Screw ×4****(T)****Washer ×4**

NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

02

(S)





M6*30 Screw ×4

(T)



Washer ×4



NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

03

(S)





M6*30 Screw ×4

(T)



Washer ×4






NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

04

(L)




M6*25 Screw ×8




NOTE:IF ANY SCREW HOLES CANNOT BE ALIGNED, LOOSEN ALL THE SCREWS AND GO BACK STEP 1 AND RESTART ASSEMBLY.

05




Glass Top x 1

Step 1: Tuck the prickly tie out of the seam at the bottom of the sofa. Pull out the prickly tie from the surface of the sofa to spread out and adjust to the right position.



U-Shaped Connector



How to Assemble End Cap

You can cover all the holes by press in the end caps.

