

### 4008 0115 Pull Out Wood Waste Basket

## **INSTALLATION GUIDE**



The Dowell Installation Guide serves as a general reference, offering step-by-step guidance for renovation professionals. The tools and fixtures supplied by Dowell for attaching to clients' floors or walls are intended as examples and might not be suitable for all types of surfaces. For optimal results, we recommend engaging a qualified professional to select the appropriate hardware for your specific installation needs. Dowell assumes no responsibility for complications arising from incorrect installation or the improper use of tools, including any subsequent damages.




# Pull Out Wood Waste Basket Installation Instructions

# 1 IMPORTANT:


Before you begin, make sure you familiarize yourself with all the parts and fully read the instructions.

## **2** TOOLS NECESSARY:

Screw gun or Phillips screwdriver, and tape measure. NOTE: If screw gun has a clutch, set to lowest setting so as not to over tighten and/or strip screws.



#### **Recommended Tools**







#### STEP 1


Push the red buttons outward on both sides together to unlock the bin from the slides.



#### STEP 2

Remove the cabinet door. Put the frame into the cabinet, adjust the frame to the appropriate location (right and left, front and back) , and secure the frame with screws.







**STEP 4**Attach the door mount bracket to the frame using the screws.





#### STEP 5

After installing the door mount bracket, use double-sided adhesive stick the door and door mount bracket together, and tighten the screws. If the location of the door plank is not appropriate, loosen the screws, adjust the door plank to the appropriate location and re-tighten the screws.



#### STEP 6

Put the trash can in the bin.