


**ASSEMBLY INSTRUCTIONS**  
**ITEM NO: 194S1203BE/CC/GY/YW-1**  
**ACCENT CHAIR**

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.



**Care Instruction for Microfiber Furniture:**

In order to maintain the original appearance of your Microfiber furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Microfiber.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connection are tight. Re-tighten if necessary.



For item use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/ scratches and discoloration.