



— ENJOY LIFE · SHARE HAPPINESS —

INSTRUCTION MANUAL



3PCS Cast Aluminum Bistro Set

SCD010-01

INTRODUCTION

Thanks for purchasing and trusting NUUGARDEN with your home decorating plans. This product is a piece of furniture designed and made by NUUGARDEN Corp.

We are committed to R&D and innovation and creating the most exquisite and diverse outdoor series.

After unpacking and before every use, check whether the item shows any damage. In addition, check that you have all parts and hardware before assembly. If there is any damage, please do not use it and call customer service at (800) 257-7108 or email service@nuugarden.com. If you do not have all the parts lists, have your dealer contact us and we will send them to you immediately.




This item of furniture is intended for indoor and outdoor use. Please take time to read and follow the instructions below. Then, use this item as described in this operating manual. We accept no liability for damage caused by improper use.



SCAN ME!

For more assembly instructions,
please visit our Youtube channel.

<https://www.youtube.com/@nuugardenusa>



Part Number	Images and Sizes	Qty.
A		1
B		1
C		2
D		2
E		1
F		1
G	 M6*30	2
H	 M6*ø15	6


M	 M8*ø12	10	I	 M6*ø9.5	6
N	 M8	10	J	 M6	6
O	 M6	6	K	 M6*25	4
P	 M8	10	L	 M8*ø18	10

ASSEMBLY INSTRUCTIONS



CAVEAT

Note: Please only tighten any bolts once all bolts place correctly and the product is lying flat. If you tighten one bolt, it may cause other bolts to get out of position.



STEP 1


Attach the front and rear legs (C&D) to the bolts of the seat (B) using 10 washers (L), 10 spring washers (M) and 10 nuts (N). Do not over-tighten.

ASSEMBLY INSTRUCTIONS



CAVEAT

Note: Please only tighten any bolts once all bolts place correctly and the product is lying flat. If you tighten one bolt, it may cause other bolts to get out of position.





STEP 2

Attach the backrest (A) to the armrest (E&F) using 2 bolts (G), 2 washers (H), 2 spring washers (I), and 2 nuts (J). Do not over-tighten.

Connect the arm (E&F) and the chair seat (B) with 4 bolts (K), 4 washers (H), 4 spring washers (I), and 4 nuts (J).

Upon completing the entire assembly and bolting up, you can tighten down all screws, and place the protective cap (O&P) on all screws.



Part Number	Images and Sizes	Qty.
A		1
B		1
C		3
D	 M8*35	3
E	 M8*ø18	3
	 M8*ø12	3
	 M8	3
	 M6*30	6


			I	 M6*ø15	6
L	 M6	6	J	 M6*ø9.5	6
M	 M8	3	K	 M6	6

ASSEMBLY INSTRUCTIONS



CAVEAT

Note: Please only tighten any bolts once all bolts place correctly and the product is lying flat. If you tighten one bolt, it may cause other bolts to get out of position.



STEP 1


Attach the 3 legs (C) to the table top (A) using 3 bolts (D), 3 washers (E), 3 spring washers (F) and 3 nuts (G). Do not over tighten.

ASSEMBLY INSTRUCTIONS



CAVEAT

Note: Please only tighten any bolts once all bolts place correctly and the product is lying flat. If you tighten one bolt, it may cause other bolts to get out of position.



STEP 2

Attach the 3 legs (C) to the legs support (B) using 6 bolts (H), 6 washers (I), 6 spring washer (J) and 6 nuts (K). Do not over tighten.

Upon completing the entire assembly and bolting up, you can tighten down all screws, and place the protective cap (L&M) on all screws.

CARE AND MAINTENANCE

Follow the instructions for the product's material to ensure it stays in the best shape as long as possible. The information below is a general guideline.

Don't hesitate to get in touch with us to learn more.

- Only rinse it thoroughly with clean water to wash away dirt and grime. Never use abrasive cleansers on the furniture since they can attack the surface and leave behind scratch marks.

- For stubborn grime and stains, use a soft sponge and mild soapy water.

Then dry it with a cloth or paper towel.

- Check the stability of the screws, nuts, and nut caps before each use.

Then, tighten them up after one to two months' use whenever required.

- Avoid improper use, and be careful not to scratch or damage the surface with sharp objects.

- When you move your furniture, lift it rather than pulling or pushing it to avoid damaging the floor, legs, and mounting.

CUSTOMER SERVICE

Thanks for purchasing NUUGARDEN furniture. We are here to help you maximize your enjoyment and appreciation of it.

Please do not hesitate to contact our customer service if you have any questions regarding assembly or accessories.

Add: 6366 Corley Road, Norcross, GA 30071.

Tel: (800) 257-7108

Web: <https://nuumart.com>

E-mail: service@nuugarden.com

Service time: Mon-Fri, 8:30 AM-5:30 PM, EST



NUUGARDEN USA



Nuu Garden Corp.

Add: 6366 Corley Road, Norcross GA 30071.

Tel: (800) 257-7108

Web: <https://nuumart.com>

E-mail: service@nuugarden.com