

<b>Product Name:</b>	7.5Ft Pre-Lit Flocked Slender Artificial Pine Christmas Tree
<b>SKU #:</b>	WHAP2055

Thank you for purchasing this LuxenHöme product. This product has been manufactured with the highest standards of safety and quality.

**PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.**

Unpack all parts from inside the carton to ensure there are no missing or damaged parts. If any parts are missing or damaged, do not attempt to assemble or use the product.

**CARTON CONTENTS:**

Description	Quantity
Tree Top	1
Tree Body	3
Metal stand	1

**Before You Start**

1. Decide on an appropriate location for your product, please read assembly and Instruction procedure carefully.  
Note: These trees are for indoor display only.
2. Retain the instructions for future use and save the carton for storing your tree.



<b>Product Name:</b>	7.5Ft Pre-Lit Flocked Slender Artificial Pine Christmas Tree
<b>SKU #:</b>	WHAP2055

### Assembly and Instruction Procedure (no tools required for assembly):

Remove all packaging (i.e., cardboard or plastic) before beginning. We suggest unpacking the trees on a large cloth for easy clean up. Some of the snow flocking may come off during unpacking and fluffing of branches.

- Place the pots on a level surface before assembling. Insert the tree body into the pot firmly.
- Gently lower all branch tips on tree. Be aware not to put excessive pressure on the brackets during assembly.
- The branches can be adjusted to give your tree a certain fullness. For the best results, straighten and separate all branch tips, then bend them slightly outward.

**Tip:** start with tips closest to the pole. One tip to the right, one to the left, and one at the center of the main stem. Repeat pattern for each branch.



### Warnings:

1. Risk of Fire and Electric Shock – please follow instructions and warnings on string lights if adding lights to trees.
2. Do not place it near fireplaces, candles, outdoor heaters, or other similar sources of heat. The trees are not flame retardant.
3. Do not install nearby pools, fountains, tubs, sinks, or outdoor areas with standing water that the tree may fall or blow into.
4. Make sure the final assembly is stable enough to hold the tree upright.
5. This product is for decoration use only. Not to be used by children as a toy. Keep out of reach of small children.

### Troubleshooting:

- Some bulbs are not lighting, or lights do not come on at all: Search for any loose plug connections between the tree sections. Search for loose or missing bulbs.
- Tree is not straight: Make sure the tree is firmly inserted into the pot. It is better if the tree is in the vertical position when adjusting.

Note: If this does not resolve the issue with the trees, please do not disassemble the trees yet. Please contact customer service for assistance.

### Storage:

1. Remove all decorations.
2. Remove each section from the pot. Press the tree tips back up against the pole.
3. Place the trees back into the carton, putting the largest one on the bottom.
4. Store the product in a cool, dry location protected from sunlight where the temperature does not exceed 35°C (95°F).